



Embedded Systems SIA, VAT No LV40003411103
47. Katolu str., Riga, LV 1003, LATVIA
Phone: +371 67648888, fax: +371 67205036, e-mail: sales@openrb.com


1. Extract en.stsw-stm32080.zip and install DfuSe_Demo_V3.0.5_Setup
2. Open **DfuSeDemo** program



3. Connect CAN device to PC via microUSB-USB cable (make sure 24V DC is DISCONNECTED from the device). Press **RESET** button prior connecting USB to PC. While the button is pressed, connect cable from the PC to device. It will set up drivers automatically. You should see then such picture. Make sure you see **STM Device in DFU Mode** under Available DFU Devices.



4. Click **Choose**, choose firmware DFU file (8rel_v4.dfu for 8 relay module), enable check-box for „**Verify after download**”. Press **UPGRADE** button.



5. After successful upgrade you see the following screen.

